


User Guide Site Storage Box



Product Information Specification



¹ Working Load Limit		¹ Wo	rking	Load	Limit
---------------------------------	--	-----------------	-------	------	-------

Height (External)	Height (Internal)	Width (External)	Width (Internal)	Length (External)	Length (Internal)	Weight
636mm	529mm	678mm	534mm	1225mm	1054mm	65kg

Overview

Key Benefits

and durability.

•

.

.


.

۰

.

Product Information **Parts Diagram**

Site Storage Box



	1.		
NOTE: These parts are for this mode	l, they may differ for previo	us versions. Please contact Conquip with any	queries.

Item Number	Part Number	Description	Quantity
1	Х	Lock Mechanism	2
2	Х	200mm Stroke Length Gas Strut, F=300N	2
3	Х	M6 x 20 Hex Head Bolt	1
4	NS800826	M6 Nyloc Nut	1
5	NS800737	M6 Washer Form A	1
6	NS800666	M10 x 20 Hex Head Bolt	4
7	NS800715	M10 x 45mm	4
8	NS800017	M10 Full Nut	4
9	NS800013	M10 Nyloc Nut	8
10	NS800262	M10 Washer	4

Original Working Instructions **Usage Instructions**

Important Usage Notes

- The Site Storage Box is designed to be lifted when empty only.
- Do not raise or transport whilst storing equipment or materials.
- Do not use to store any hazardous chemicals.

Usage Instructions

- 1. To lift the Site Storage Box with a forklift, set the machine's forks to the correct width for the Site Storage Box's fork pockets. Make sure that they are equidistant from the centre.
- 2. Drive the telehandler to the Site Storage Box aligning the forks with the fork pockets.
- 3. Move the forklift forward until the forks are fully inserted into the fork pockets. The box is now ready to move.
- 4. Carefully raise the box just off the ground and check for balance and security.
- 5. Carefully transport the box to its required destination, taking care not to jolt.
- 6. When in position, the box can be lowered onto flat, firm, level ground.
- 7. Reverse the forklift back and clear of the box.
- 8. To open the door, unlock both locks and use the handle to lift the door up and over, taking advantage of the gas struts.
- 9. Load the box with materials and close and lock the door for security measures.

Original Working Instructions **Safety Instructions**

Basic Safety

A site-specific Risk Assessment, and lift plan where applicable, must be completed by the responsible person before using this equipment to control risks, produce a safe system of work and ensure safety for you, your colleagues and others. Your risk assessment will determine the correct Personal Protective Equipment (PPE) for the task you are doing. You must use it. Conquip recommends that you should wear:

- Suitable clothing
- Gloves
- Hard hat
- Protective footwear (steel toecaps)
- Safety glasses



Important Safety Notes

- Read these instructions before using this equipment. If there is anything you do not understand or if you have any concerns do not use this equipment. Contact your supervisor or Conquip Engineering Group for advice.
- You must check that you have considered all the safety requirements for the task you are doing and that this equipment is suitable.
- You must protect bystanders and the general public by preventing access to the working area.
- Do not use this equipment if you are tired, unwell or under the influence of alcohol or drugs. If you are taking any medicine or undergoing treatment you should inform your supervisor.

Usage & Transportation

- Never unevenly load this equipment.
- The weight of the equipment, together with its attachments, must be added to the weight of the load when calculating the total load that will be imposed on the lifting apparatus / operating machine.
- This equipment must be used in conjunction with the load ratings of the lifting apparatus / operating machine. (Refer to the manufacturers' load ratings and original working instructions).
- Make sure you know how to use this equipment and understand all aspects of its operation in case of emergency.
- This equipment weighs more than 25kg. Do not lift or manhandle without machine assistance.
- Do not operate this equipment near overhead power lines.
- Take care in confined spaces, near ceilings or similar hazards. This equipment was designed for vertical lifting. Do not drag, or swing.
- Before operating this equipment, check that you have enough space for you to work safely and make sure that the working area is clear of hazards, obstructions and personnel.
- Before lowering equipment make sure that the landing zone is clear and capable of accepting the size and weight of the load.
- Crush Risk. Keep hands and feet clear of the equipment at all times to avoid injury.
- Do not exceed the maximum Working Load Limit (WLL) shown on the serial plate. Ensure that the WLL
 on the individual lift points is not exceeded.
- Manoeuvre loaded or raised equipment carefully. Travel and turn slowly to avoid unit becoming unstable.

Personnel

- All personnel must wear relevant personal protective equipment.
- Do not wear loose clothing or jewellery and tie back long hair to avoid becoming tangled or trapped in this equipment. You must make everyone in the work area aware of what you are doing.
- All personnel involved in the lifting operation must be competent to do so and must have been briefed in conjunction with this User Guide available from Conquip Engineering Group, the manufacturer.

Equipment Maintenance & Cleaning

- It is mandatory that the equipment is thoroughly examined regularly, by a qualified engineer, to ensure compliance with relevant regulation/s. (Conquip recommend to carry out thorough examination every six months).
- This product may incorporate various loose and detachable items of lifting gear. Refer to the separate requirements for the safe use of those items.
- When not being used, store the unit in a clean, upright condition and in a safe place where it will be protected from thieves and unauthorised users.
- This equipment must be inspected by the responsible person before each use and then regularly, as determined by your risk assessment or working practice. If you have any concerns about condition or suitability do not use.

Disclaimer

Warranty

The products supplied by Conquip Engineering Group are all guaranteed by a 12 month warranty.

Apart from where exceptions apply, Conquip Engineering Group promises to repair or replace any fault which the Company considers to be due to defective material or workmanship within 12 months of the date of sale, at no additional cost.

- Faults arising from unauthorised alterations (see modifications section below for full details).
- Damage caused by abuse, neglect, misuse or falling.
- Damage caused because of failure to follow transportation, storage, loading, cleaning or operating instructions.
- Replacement or repair of components due to fair wear and tear.
- Any consequential damage or wear arising from the use or fitting of additional or non-standard parts.

Modifications

If any third-party modifications or alterations, involving drilling, welding, cutting or distortion of materials in any form, are to be carried out on the product, Conquip Engineering Group must provide full written approval prior to the work being carried out.

Alterations, modifications, additions or repairs must be carried out by Conquip Engineering Group's recognised distributors, if they are not carrying out the work themselves.

Conquip Engineering Group operate a continuous improvement policy and therefore reserve the right to alter technical specifications and user guide details at any point without notice.

Conquip Engineering Group will not cover or reimburse any transportation and/or shipment costs to and from their premises or their recognised agents, or any material and/or labour costs for repair, replacement or assessment against a warranty claim.

Conquip Engineering Group and/or their directors, employees, insurers or recognised agents will not be held liable for consequential damages, losses or expenses relating to the inability to use the product correctly for its purpose.

EC Declaration of Conformity

In accordance with EN ISO 17050-1:2004

Declaration: As defined by the Machinery Directive 2006/42/EC and subsequent amendments

We, CONQUIP ENGINEERING GROUP, herewith declare that the following indicated equipment meets the fundamental health and safety requirements concerning the EU guide line(s), due to their design and manufacture.

This declaration will be rendered null and void if the machine is changed without our approval.



Dated: 2018

Garry Critchley, Managing Director

Product Code(s):	ST104-00523
EC Directive/ Regulation:	2006/42/EC, Lifting Operations and Lifting Equipment Regulations 1998 Provision and Use of Work Equipment Regulations 1998
Harmonised Standards:	BS EN ISO 12100:2010
General Description/ Designation:	Site Storage Box – ST104-00523
WLL:	ST104-00523 = N/A

Important Notes

- This User Guide is for this Conquip product only.
- Any movements of the product must be thoroughly planned before the work commences to identify
 potential hazards and assess risk.
- All personnel involved in lifting and transportation of this product must have read this User Guide and must be properly briefed.
- You must be competent, alert and medically fit when using this equipment. If you have a medical
 condition, a mental or physical disability, you must seek advice from a medical professional before using
 this equipment.

Talking to us is easy We're here to help

Call us on 0845 520 1101 Email us at sales@cqegroup.com www.cqegroup.com

Conquip Engineering Group

Waterbrook Estate, Alton, Hampshire, GU34 2UD

Copyright © 2019 Conquip Engineering Group. All Rights Reserved. Site Storage Box User Guide - Issue 2 $\,$